

## SHV Plug to SHV Plug Cable Using RG393 Coax



# **RF Cable Assemblies Technical Data Sheet**

## Configuration

- Connector 1: SHV Plug
- Connector 2: SHV Plug
- Cable Type: RG393

#### **Electrical Specifications**

Description	Minimum	Typical	Maximum	Units
Frequency Range	DC		300	MHz
RF Shielding	60			dB
Capacitance		29.4 [96.46]		pF/ft [pF/m]
Operating Voltage (AC)			3,500	Vrms
Dielectric Withstanding Voltage (AC)			5,000	Vrms

#### **Specifications by Frequency**

Description	F1	F2	F3	F4	F5	Units
Frequency	50	100	250	500	1,000	MHz
Insertion Loss (Max.)	0.21	0.22	0.23	0.25	0.28	dB/ft
	[0.69]	[0.72]	[0.75]	[0.82]	[0.92]	[dB/m]

#### **Mechanical Specifications**

Cable Assembly Diameter Weight

#### Cable

Cable Type Impedance Inner Conductor Type Inner Conductor Material and Plating Dielectric Type Number of Shields Shield Layer 1 Shield Layer 2 0.57 in [14.48 mm] 0.269 lbs [122.02 g]

RG393 50 Ohms Stranded Copper, Silver PTFE 2 Silver Plated Copper Braid Silver Plated Copper Braid

Click the following link (or enter part number in "SEARCH" on website) to obtain additional part information including price, inventory and certifications: SHV Plug to SHV Plug Cable Using RG393 Coax PE3338

Pasternack Enterprises, Inc. • P.O. Box 16759, Irvine, CA 92623 Phone: (866) 727-8376 or (949) 261-1920 • Fax: (949) 261-7451

Sales@Pasternack.com • Techsupport@Pasternack.com

## **PE3338**



# SHV Plug to SHV Plug Cable Using RG393 Coax



**PE3338** 

## **RF Cable Assemblies Technical Data Sheet**

Jacket Material Jacket Diameter

One Time Minimum Bend Radius

#### Connectors

Description	Connector 1	Connector 2	
Туре	SHV Plug	SHV Plug	
Specification	MIL-STD-348A	MIL-STD-348A	
Impedance	50 Ohms	50 Ohms	
Contact Material and Plating	Brass, Gold	Brass, Gold	
Contact Plating Specification	30µ in. minimum	30µ in. minimum	
Dielectric Type	Teflon	Teflon	
Coupling Nut Material and Plating	Brass, Nickel	Brass, Nickel	
Coupling Nut Plating Specification	100µ in. minimum	100µ in. minimum	
Body Material and Plating	Brass, Nickel	Brass, Nickel	
Body Plating Specification	100µ in. minimum	100µ in. minimum	

FEP, Tan

0.39 in [9.91 mm]

3.9 in [99.06 mm]

#### Compliance Certifications (see product page for current document)

#### **Plotted and Other Data**

Notes:

Click the following link (or enter part number in "SEARCH" on website) to obtain additional part information including price, inventory and certifications: SHV Plug to SHV Plug Cable Using RG393 Coax PE3338

Pasternack Enterprises, Inc. • P.O. Box 16759, Irvine, CA 92623 Phone: (866) 727-8376 or (949) 261-1920 • Fax: (949) 261-7451

Sales@Pasternack.com • Techsupport@Pasternack.com



## SHV Plug to SHV Plug Cable Using RG393 Coax



# **RF Cable Assemblies Technical Data Sheet**

PE3338

# How to Order Part Number Configuration: **PE3338** uu - XX - Unit of Measure: cm = Centimeters <blank> = Inches Length Base Number PE3338-12 = 12 inches long cable Example: PE3338-100cm = 100 cm long cable SHV Plug to SHV Plug Cable Using RG393 Coax from Pasternack Enterprises has same day shipment for domestic and International orders. Our RF, microwave and millimeter wave products maintain a 99% availability and are part of the broadest selection in the industry. Click the following link (or enter part number in "SEARCH" on website) to obtain additional part information including price, inventory and certifications: SHV Plug to SHV Plug Cable Using RG393 Coax PE3338 URL: https://www.pasternack.com/shv-plug-shv-plug-rg393u-cable-assembly-pe3338-p.aspx The information contained in this document is accurate to the best of our knowledge and representative of the part described herein. It may be necessary to make modifications to the part and/or the documentation of the part, in order to implement improvements. Pasternack reserves the right to make such changes as required. Unless otherwise stated, all specifications are nominal. Pasternack does not make any representation or warranty regarding the suitability of the part described herein for any particular purpose, and Pasternack does not assume any liability arising out of the use of any part or documentation.

Pasternack Enterprises, Inc. • P.O. Box 16759, Irvine, CA 92623 Phone: (866) 727-8376 or (949) 261-1920 • Fax: (949) 261-7451

Sales@Pasternack.com • Techsupport@Pasternack.com

# PE3338 CAD Drawing SHV Plug to SHV Plug Cable Using RG393 Coax



